



NOTE:

ONE-HALF INCH CHAMFERED (CONTROL) JOINTS SHALL BE PLACED AT EVERY TWO-PANEL INTERVAL COINCIDING WITH EVERY OTHER PANEL JOINT. ONE-HALF INCH EXPANSION JOINTS SHALL BE PLACED AT EVERY FOUR-PANEL INTERVAL WHEREBY ALL LONGITUDINAL REINFORCEMENT SHALL BE FIELD CUT TWO INCHES (2") SHORT OF EACH SIDE OF THE EXPANSION JOINTS.

C.I.P. COPING ELEVATION

SCALE: 1/4" = 1'- 0"

IMPORTANT NOTE ABOUT DIMENSIONS

Dimensions used in this document are for illustrative purposes only and may vary slightly from precise design or fabrication dimensions due to English/Metric conversion or due to simplification appropriate to the guideline character of this manual. When required for design, precise dimensions (each project uses either English or Metric) should be obtained from contract plans or directly from The Reinforced Earth Company. RECo reserves the right to change the dimensions of fabricated materials as needed.



C.I.P. COPING ELEVATION
CRUCIFORM & SQUARE PANELS

FIGURE NO.	CIP.COP.ELEV 1
DATE	10/25/2016